



# L-810 Solar Angle Setting Guide:

1. Solar panel must face equator and have good exposure to sunlight
2. Using the map below, select your angle setting and secure using provided wing nuts

